




MODEL 385 & 485

**PARTS
CATALOG**



CRITTENDEN CONVERSION CORPORATION

Special care has been given to the design and manufacture of your conversion to make it as trouble-free as possible. Nevertheless, there will be occasional instances of malfunctioning which, if dealt with systematically, can usually be corrected by your regular maintenance personnel. The following instructions are set forth to help you analyze your machine in order to locate and correct any difficulties that should occur.



OPERATION SEQUENCE

As flap of box hits Trip Gate, LS1 is closed, energizing C1 start side of Solenoid Valve, causing 2" x 2" Air Cylinder to retract, shifting Main Clutch/ Brake to contact Flywheel.

High Speed Clutch is now disengaged, Crank Rod is moving Step-Feed Shaft. The Overrun of the Step-Feed Shaft is controlled by the Auxiliary Brake, which is energized only in stitch position. You will note that Auxiliary Brake Air Regulator indicates pressure only while stitching.

The *spacing between stitches* is controlled the same as before conversion.

The *number of stitches* will be determined by the following:

You will have one of two models of counters.

With the **Model 102 Counter** you will be able to count stitch.

With the **Model 204 Counter** you will be able to count stitch and count tie-stitch.

The last stitch is controlled by the Reed Switch (RS1) which closes each time the Magnet, mounted on aluminum disc on end of Crank Shaft, passes by Switch.

Upon completion of last stitch, the counter emits an output on Terminal number 4, energizing C2 stop side of Solenoid Valve causing 2" x 2" Air Cylinder to extend, shifting Main Clutch/Brake to contact Stationary Brake Plate. High Speed Clutch engages, causing ejection of completed box.

The following is an example of Model 204 Counter setup to assist you when setting up to run a box that requires tie-stitching.

TIE-COUNT REQUIREMENTS:

16 total stitches with 1 tie at front of box and 1 tie at back of box.

COUNTER SETTINGS WOULD BE:

Counter Switch—on, Tie Stitch Switch—on

Total Knobs—left knob on 1, right knob on 6.

Back Tie Knobs—left knob on 1, right knob on 5.

Front Tie Knob—on 1.

From this you will note that the front tie setting is a direct reading, where the back number of ties is attained by subtracting the back tie setting from the total setting.

TROUBLE SHOOTING

Machine Will Not Start Stitching

1. Check N.O. LS1 micro switch and wiring to junction box.
2. Check solenoid valve for excessive oil, foreign matter, etc.
3. Check wiring to solenoid valve.
4. Check for sticking bottom rail on trip frame.
5. Check for 110 VAC across terminals 1 and 4. This should be a momentary signal only. A constant signal will prevent stitcher from starting as this is the stop circuit.

Machine Will Not Stop Stitching

1. Check RS1 N.O. reed switch (count input).
2. Be sure counter switch is in on position.
3. Be sure counter mode switch is in count position.
4. Check for 110 VAC output between terminals 1 and 4 (stop circuit). **NOTE:** This should be a momentary signal at end of each stitch cycle.
5. Check solenoid valve and wiring.
6. Check for loose magnet disc. or missing magnet.
7. Check to see that N.O. LS1 micro switch is not stuck closed.

After Stitching, Box Does Not Eject Satisfactorily

1. Check high speed clutch adjustment.
Caution: Do not overtighten, as this will cause erratic stopping. Tighten only to the point where box ejects properly.
2. Be sure trip is not set to low, causing excessive drag between gate and box.
3. Check auxiliary brake regulator for sticking open.

Feed Rolls Stop and Fail to Eject Box After Completing the Stitching Cycle and the Stitcher Motor is Still Running

1. Check shifting linkage for missing or broken parts.
2. Check auxiliary brake regulator for sticking open.

Front End of Boxes Being Excessively Broken Down Due to Impact with Trip Gate

1. Feed rolls too tight.
2. Restrictor valve on trip is closed too far and not allowing gate to open fast enough.

Boxes Show Stitch Deformation or Tearing

1. Check mechanical timing (head drive cam with respect to crank shaft). Refer to Bostitch manual.

Placement of First Stitch Erratic

1. Restrictor valve on trip open too far.
2. Feed rolls too loose.

Boxes Come out of Machine with no Staples

1. Check head for faulty wire feed mechanism or wire may be tangled on spool.

First Two Staples Too Close Together or on Top of One Another

1. Restrictor valve on trip closed too far.
2. Faulty step-feed clutch.

Erratic Placement of Stitches

1. Feed rolls too loose.
2. Auxiliary brake not holding properly due to low air pressure, worn discs or oil on brake disc.
3. Faulty step-feed clutch.
4. Grease, wax or oil on feed rolls.
5. Box guides set too tight.

Machine Puts in Wrong Number of Staples

1. Check counter settings.
2. Check for faulty RS1 N.O. reed switch.
3. Check for loose magnet disc and adjustment of reed switch position with respect to magnet.
4. Check for faulty counter or plug in modules.

Machine Stops Consistently with Formers in Wrong Position (Down)

1. Loosen magnet disc and rotate CW or CCW until desired stopping position of head is attained. Be sure to firmly tighten disc retaining bolt.

Erratic Stopping of Machine (More Than a Total of Approx. 20 Degrees)

1. High speed clutch too tight.

2. Grease or oil on main brake lining.
3. Binding in main shifting air cylinder.
4. Loose main brake disc.

Machine Stops and Cannot be Turned Over By Hand

1. Check stitch head for wire jamming or broken parts.
2. Check to see that connecting rod is not frozen to eccentric.
3. Check for sticking auxiliary brake regulator.


Will Not Tie-Stitch

1. Re-check counter settings.
2. Mode switch is not in "tie" position. With switch in "tie" position, tie-stitch air cylinder should be retracted. If not, check the following:
 - a. Tie-stitch solenoid valve (TSC-1).
 - b. Tie-stitch air cylinder.
 - c. Pinched or broken air lines.
 - d. Check electrical circuit, including counter for loose or broken connections.
 - e. Replace plug-in module in counter.
3. If cylinder is retracted but will not tie-stitch:
 - a. Check tie-stitch bell crank mechanism for proper adjustment and broken parts.


Wrong Number of Tie Stitches

1. Recheck counter settings.
2. Check for binding of tie-stitch air cylinder.
3. See 3 (a) above.
4. See 2 (e) above.


SECTION A





SECTION A



SECTION B



SECTION B



RECOMMENDED SPARE PARTS		
QTY.	PART NO.	ITEM
1	498	Stitch Counter
1	491	Reed Switch
1	450A	Magnet
1	497	Solenoid Valve
1	483	Air Cylinder
1	411	Overrunning Clutch
1	413	Auxiliary Brake
2	440D	Clutch/Brake Disc
		W / Facing
1	425C	High Speed Clutch Disc
		W / Facing


**PARTS LIST FOR MODELS
385 and 485**



CRITTENDEN CONVERSION CORPORATION

400	TOP FEED ROLL SHAFT	426	HIGH SPEED SPROCKET	465	OVERRUNNING CLUTCH HUB
401	TOP FEED ROLL SPROCKET— 16 TOOTH	427	SNAP RING		CASTING
402	TOP UNIVERSAL JOINT	428	BEARING—SL-16	470	AUXILIARY BRAKE GUARD
403	TOP JACK SHAFT	430	CRANK SHAFT	475	BASE PLATE
404	REVERSE GEAR SHAFT	435A	SPROCKET	476	SHAFT
405	TOP REVERSE GEAR	435B	BEARING # SL 15	477	SHAFT
406	BOTTOM REVERSE GEAR	435C	SNAP RING	478	SCREW
407	STEP FEED SHAFT	435D	THRUST BEARING # E8	479	SCREW
408	BOTTOM UNIVERSAL JOINT	435F	FLYWHEEL	480	TURNBUCKLE ASSY.
409	BOTTOM JACK SHAFT	435	FLYWHEEL ASSY. COMPLETE		COMPLETE
410	BOTTOM FEED ROLL SHAFT	440	CLUTCH/BRAKE ASSY. COMP.	483	AIR CYLINDER
411	OVERRUNNING CLUTCH	440A	CLUTCH & BRAKE SLEEVE	486	ROD END # FR 8
411A	OVERRUNNING CLUTCH KEY	440B	COLLAR	487	AIR CYLINDER CLEVIS
412	AUXILIARY BRAKE HUB	440C	THRUST BEARING # E25	487A	AIR CYLINDER CLEVIS PIN
412A	AUXILIARY BRAKE DISC	440D	CLUTCH & BRAKE DISC	490	TRIP LATCH PADDLE
413	AUXILIARY BRAKE	442	BRAKE PLATE	491	REED SWITCH
414	AUXILIARY BRAKE MOUNT	443	V-BELT # 3 V 475	492	REED SWITCH CLAMP
415	SPROCKET	444	BUSHING	493	LOCK WASHER
416	HIGH SPEED SHAFT	445	SHEAVE	494	SCREW
417	SCREW	450	DISC	495	CHAIN # 40
418	WASHER	450A	MAGNET	497	SOL. VALVE B02 (NOT SHOWN)
419	THRUST BEARING # E9	455	SHAFT	498	STITCH COUNTER (NOT SHOWN)
420	SQUEEZE-LOCK	456	BELL CRANK		(SPECIFY TYPE)
421	KEY	456A(2)	BELL CRANK BUSHING	OC1-1	HIGH SPEED CLUTCH ARM
422	LOCK COLLAR	458	STITCH SPACE LEVER	OC1-2	CLUTCH/BRAKE ARM
425A	HIGH SPEED CLUTCH SLEEVE	458A(2)	BUSHING	OC1-3	CLUTCH/BRAKE SHIFTING
425B	THRUST BEARING # E20	459	SHOULDER SCREW		YOKE
425C	HIGH SPEED CLUTCH DISC W/FACING	460	NUT	OC1-4	HIGH SPEED CLUTCH YOKE
425	HIGH SPEED CLUTCH COMPLETE	461	T-SLOT NUT	OC1-5	LARGE BEARING HOUSING
		462	SCREW		CASTING
		463	HARD WASHER	OC1-6	SMALL BEARING HOUSING
		464	BUSHING		CASTING




385 & 485 TRIP/GATE ASSY. & FEED ROLL LIFT ADJUSTER




RECOMMENDED SPARE PARTS

QTY.	PART NO.	ITEM
1	11	Start Switch
1	21	Lift Cylinder
1	28	Latch Cylinder


4101	TRIP FRAME	18	ADJUSTING ROD	37	SPRING
4102	SLIDE RAIL	19	LOCK HANDLE	38	LINK
1 (4)	SPACER	20	SPRING PIN	39	LATCH CAM
2 (4)	LOCK WASHER	21	LIFT CYLINDER	40 (4)	SCREWS
3 (4)	SCREW	22	SCREW	41 (2)	SHOULDER SCREW
4	SCREW	23	LOCK WASHER	42 (2)	JAM NUT
5	CABLE CLAMP	24	NUT	43	TRIP GATE
6	RESTRICTOR VALVE	25	ROD END—TF-7	44	LOCK SCREWS
7 (3)	POLY-FLO FITTING	26	JAM NUT	45	SIDE RAIL
8	BRACKET	27	SPRING PIN	46	SLIDE BLOCK
9	SCREW	28	LATCH CYLINDER	47	KEY
10	SCREW	29	SCREW	48	NUT
11	MICRO SWITCH—OCT-35	30	SCREW	49	SIDE RAIL
12	SCREW	31	LATCH	50	ROD END—TF-5
13	LOCK WASHER	32	LATCH ECCENTRIC	51	POLY-FLO FITTING
14	LIFT PLATE	33	SCREW	52	NUT
15	SET SCREW	34 (2)	SCREW	53	SPRING
16	KNOB	35	SHOULDER SCREW	54	SPRING ADJ. SCREW
17	GUIDE	36	SHOULDER SCREW		




REED SWITCH



MODEL 102 COUNTER



MODEL 204 COUNTER



PNEUMATIC CIRCUIT

